



MG RV8

R380 gearbox

overhaul manual

R380

GEARBOX

OVERHAUL

MANUAL



INTRODUCTION

How to use this manual

To assist in the use of this manual the section title is given at the top and the relevant sub - section is given at the bottom of each page.

This manual contains procedures for overhaul of the R380 gearbox on the bench with the clutch and, if applicable, the transfer box removed. For all other information regarding Adjustments, Removal of oil seals, clutch, transfer box and gearbox unit, consult the appropriate Repair Manual for the model concerned.

This manual is divided into 5 sections, Data, Torque Settings, Service Tools, Description and finally, Overhaul. To assist filing of revised information each sub - section is numbered from page 1.

The individual overhaul items are to be followed in the sequence in which they appear. Items numbered in the illustrations are referred to in the text.

Overhaul operations include reference to Service Tool numbers and the associated illustration depicts the tool in use. Operations also include reference to wear limits, relevant data, torque figures, and specialist information and useful assembly details.

WARNINGS, CAUTIONS and Notes have the following meanings:

WARNING: *Procedures which must be followed precisely to avoid the possibility of injury.*

CAUTION: *Calls attention to procedures which must be followed to avoid damage to components.*

Note: Gives helpful information.

References

Operations covered in this manual do not include reference to testing the vehicle after repair. It is essential that work is inspected and tested after completion and if necessary, a road test of the vehicle is carried out, particularly where safety related items are concerned.

Dimensions

The dimensions quoted are to design engineering specification with Service Limits where applicable.

REPAIRS AND REPLACEMENTS

When replacement parts are required it is essential that only Rover/Land Rover recommended parts are used.

Attention is particularly drawn to the following points concerning repairs and the fitting of replacement parts and accessories.

Safety features embodied in the car may be impaired if other than Rover/Land Rover recommended parts are fitted. In certain territories, legislation prohibits the fitting of parts not to the manufacturers specification.

Torque wrench setting figures given in this Manual must be used. Locking devices, where specified, must be fitted. If the efficiency of a locking device is impaired during removal it must be renewed.

The Terms of the vehicle Warranty may be invalidated by the fitting of other than Rover/Land Rover recommended parts. All Rover/Land Rover recommended parts have the full backing of the vehicle Warranty.

Rover/Land Rover Dealers are obliged to supply only recommended parts.

SPECIFICATION

Rover/Land Rover are constantly seeking to improve the specification, design and production of their vehicles and alterations take place accordingly. While every effort has been made to ensure the accuracy of this Manual, it should not be regarded as an infallible guide to current specifications of any particular component or vehicle.

This Manual does not constitute an offer for sale of any particular component or vehicle. Rover/Land Rover Dealers are not agents of Rover/Land Rover and have no authority to bind the manufacturer by any expressed or implied undertaking or representation.

INTRODUCTION

GEARBOX IDENTIFICATION

The procedures given in this manual cover overhaul of the R380 gearbox fitted to a range of vehicles and as such, certain differences exist between gearboxes, particularly in respect of the extension housings, gear change housings and transfer box selector housings. It is important therefore that before starting work, the gearbox to be overhauled is correctly identified. Identification can be made by noting the gearbox serial number prefix stamped on the RH side of the gearbox casing and referring to the following table which lists three types of gearbox, A, B and C together with their appropriate serial number prefixes.

Note: The gearbox types listed are only intended as an aid to identification and do not relate to gearbox part numbers or a particular vehicle.

Overhaul operations in this manual list the applicable gearbox type referred to and it is important that the relevant operation is followed.

Type A gearbox prefixes: - 50A; 51A; 56A; 58A; 60A; 61A;

Type B gearbox prefixes: - 53A; 55A; 63A

Type C gearbox prefix: - 18A

MANUAL GEARBOX

CONTENTS

DATA	Page
DATA	1
<hr/>	
TORQUE WRENCH SETTINGS	Page
TORQUE WRENCH SETTINGS	1
<hr/>	
SERVICE TOOLS	Page
SERVICE TOOLS	1
<hr/>	
DESCRIPTION AND OPERATION	Page
DESCRIPTION	1
<hr/>	
OVERHAUL	Page
GEARBOX DISMANTLE	1
Clutch housing - Type A gearbox - Remove	1
Clutch housing - Type B gearbox - Remove	2
Clutch housing - Type C gearbox - Remove	2
Gear change/selector housings - Type A gearbox - Remove	3
Remote housing - Type A gearbox - Remove	3
Gear change/selector housings - Type B gearbox - Remove	3
Selector quadrant - Type A gearbox - Remove	4
Gear change lever yoke - Type B gearbox - Remove	4
Remote gear change - Type C gearbox - Remove	4
Extension housing - Types A and B gearbox - Remove	5
Extension housing - Type C gearbox - Remove	5
5th and reverse gear - Remove	6
Mainshaft and layshaft - Remove	7
Mainshaft - Dismantle	7
Gearbox casing and oil pump	8
Front cover - Dismantle	8
Centre plate - Dismantle	9
Extension housing - Types A and B gearbox - Overhaul	9
Gear change/selector housings - Overhaul	10
Synchromesh assemblies - Overhaul	14
Checking baulk ring clearances	15
Input shaft - Overhaul	15
Mainshaft - Inspection	16
Layshaft - Overhaul	16
Mainshaft - Reassembly	17
Reverse idle gear - Reassembly	18
Selectors - Inspection	18



MANUAL GEARBOX

CONTENTS

GEARBOX REASSEMBLE	19
Mainshaft and layshaft end float	19
Shimming	19
Assembling mainshaft and layshaft to centre plate	19
Reverse and 5th gear - Reassembly	20
Extension housing - Types A and B gearbox - Refit	22
Extension housing - Type C gearbox - Refit	22
Selector quadrant - Type A gearbox - Refit	23
Gear change lever yoke - Type B gearbox - Refit	23
Remote housing - Type A gearbox - Refit	23
Transfer box selector housing - Type A gearbox - Refit	24
Gear change housing - Type A gearbox - Refit	24
Transfer box selector housing - Type B gearbox - Refit	24
Gear change housing - Type B gearbox - Refit	24
Remote gear change - Type C gearbox - Refit	24
5th gear stop screw adjustment - Type A gearbox	24
Bias spring adjustment - Type A gearbox	24
Bias spring adjustment - Type B gearbox	25
Bias spring adjustment - Type C gearbox	25
Clutch housing - Type A gearbox - Refit	26
Clutch housing - Type B gearbox - Refit	26
Clutch housing - Type C gearbox - Refit	27





DATA

	NEW	MAX ALLOW REBUILD
Baulk ring clearances	0.5mm(0.20in)	
1st gear end float	0.05 - 0.20mm (0.002 - 0.008in)	0.327mm (0.129in)
2nd gear end float	0.04 - 0.21mm (0.0016 - 0.0083in)	0.337mm (0.133in)
3rd gear end float	0.11 - 0.21mm (0.004 - 0.0083in)	0.337mm (0.133in)
Adjust 5th - reverse hub - shim to	0.005 - 0.055mm (0.00197 - 0.0217in)	
Reverse gear idler shaft clearance	0.04 - 0.38mm (0.0016 - 0.015in)	0.380mm (0.150in)
Mainshaft end float	0.01 - 0.06mm (0.0004 - 0.0024in)	
Layshaft end float	0.01 - 0.06mm (0.0004 - 0.0024in)	
Lubricants	ATF M2C33 F or G	
Capacities	Oil cooler fitted = 3.4 litres	
	Non oil cooler type = 2.9 litres	
Sealants	Joint faces - Marston Bentley Hylogrip 2000	
	Availabe through unipart	
	Bolts and filler plug - Loctite 270 or Marston Bentley Hylogrip 640 (studlock)	



TORQUE WRENCH SETTINGS

	Nm
Oil pump to extension case	5-7
Attachment plate to gearcase	7-10
Attachment plate to remote housing	7-10
Bottom cover to clutch housing	7-10
Breather baffle	7-10
Clip to clutch release lever	7-10
Cover to gear change housing	7-10
Spool retainer to gear case	7-10
Torsion spring locknut - adjusting screw	7-10
Washer-gearlever retention	7-10
Breather	14-16
Gear lever retainer	14-17
Reverse inhibition shaft	15-18
Reverse light switch	22-26
Adjustment plate to gear change housing	22-28
Extension case to gear case	22-28
Front cover to gear case	22-28
Gear change housing to extension case	22-28
Gear lever housing to remote housing	22-28
Guide clutch release sleeve to bell hsg.	22-28
Mounting bracket	22-28
Pivot clutch lever to bell housing	22-28
Pivot plate to bell housing	22-28
Plug detent ball and spring	22-28
Plunger housing to gear change housing	22-28
Remote selector housing to extension case	22-28
Slave cylinder to clutch housing	22-28
Thermostat housing	22-28
Upper gearlever assy, to lower gear lever	22-28
Yoke to selector shaft	22-28
Filler plug	25-35
Oil level plug	25-35
Fixing gearlever assembly	47-54
Oil drain plug	47-54
Bell housing to gearbox	65-80
Clutch housing to gearbox	65-80
Output flange bolt	80-100
5th gear layshaft stake nut	204-231



SERVICE TOOLS

Note: Where the use of special tools is specified, only these tools should be used to avoid the possibility of personal injury and or damage to components.

Land Rover Number	Rover Number	Description
LRT-37-001	18G47BA	Adaptor input shaft bearing.
LRT-37-002	18G47BAX	Conversion kit
LRT-37-004	18G284AAH	Adaptor for input shaft pilot bearing track.
LRT-37-009	18G705	Puller, bearing and oil seal collar remover
LRT-37-010	18G705-1A	Adaptor for mainshaft oil seal collar.
LRT-37-014	18G1422	Mainshaft rear oil seal replacer
LRT-37-015	18G1431	Mainshaft rear support bearing track and oil seal collar replacer.
LRT-37-021	-	Adaptor for mainshaft rear support bearing track and oil seal collar replacer.
LRT-37-022	-	Adaptor for layshaft bearings.
LRT-37-023	-	Layshaft holding tool
LRT-37-024	-	Rear mainshaft bearing track remover
LRT-51-003	18G1205	Flange holder.
LRT-99-002	M547	Hand press
LRT-99-004	18G284	Impulse extractor

Service tools must be obtained direct from the manufacturers:

V.L.Churchill,
P.O. Box No. 3,
London Road,
Daventry,
Northants, NN11.4NF
England



DESCRIPTION

The R380 5 speed all synchromesh gearbox comprises an input shaft, output shaft, layshaft and reverse idler shaft .

Gearbox casings consist of a front cover, gearcase, centre plate and extension housing, all casings are located by dowels and sealed.

Selector forks for 1st/2nd and 3rd/4th gears are located on a single selector shaft inside the main gearcase whilst the selector fork for fifth and reverse gear is located on the same selector shaft inside the extension housing.

The input shaft, output shaft and layshaft are supported by taper roller bearings with all gears running on caged needle roller bearings. Output shaft and layshaft bearings end float is controlled by selective thrust washers located in the centre plate.


Lubrication is by an oil pump located in the extension housing which directs oil via internal drillings in the output shaft to lubricate the components.



GEAR BOX DISMANTLE


Service Repair No. 37.20.04

Clutch housing - Type A gearbox - Remove



37M7047

1. *If fitted:* remove and discard clips retaining clutch release bearing pads, remove bearing and clutch release lever, recover pads.




37M7048

2. Remove 2 bolts securing release lever pivot post, remove post.
3. Remove 6 bolts securing clutch housing to gearbox, remove housing.

Note: Dowel located.

MANUAL GEARBOX

Clutch housing - Type B gearbox - Remove




37M0494

1. Remove clutch release bearing.
2. Remove bolt securing spring clip to clutch release lever, remove clip.
3. Remove clutch release lever.
4. Remove 'C' clip from release lever pivot post, discard clip.
5. Remove 6 bolts securing clutch housing to gearbox, remove housing.


Note: Dowel located.

Clutch housing - Type C gearbox - Remove



37M0495

1. Pull clutch release lever off pivot post, remove lever and clutch release bearing.




37M0496

2. Remove 6 bolts securing clutch housing to gearbox, remove clutch housing.

Note: 2 longest bolts are fitted at dowel locations and have plain washers under their heads.



Gear change/selector housings - Type A gearbox - Remove




37M7049

1. Remove 4 bolts securing gear change housing, remove housing.

Note: Dowel located.

2. Remove 4 bolts securing transfer box selector housing, remove housing.

Remote housing - Type A gearbox - Remove




37M7050

1. Noting their fitted position, remove 3 bolts securing remote housing, remove housing.


Note: Dowel located.

Gear change/selector housings - Type B gearbox - Remove



37M7051

1. Remove 2 Torx screws securing gear change housing cover, remove cover; recover sealing rubber.




37M7052

2. Remove 4 bolts securing transfer box selector housing, remove housing.
3. Noting their fitted position, remove 3 bolts securing gear change housing, remove housing.

Note: Dowel located.

MANUAL GEARBOX


Selector quadrant - Type A gearbox - Remove



37M7053

1. Remove and discard set screw securing selector quadrant.
2. Move selector shaft forwards, remove quadrant.


Gear change lever yoke - Type B gearbox - Remove



37M7054

1. Remove and discard set screw securing yoke.
2. Move selector shaft forwards, remove yoke.

Remote gear change - Type C gearbox - Remove




37M7055

1. Noting fitted positions of mounting rubbers and washers, remove 2 bolts securing remote gear change to extension housing, recover washers and mounting rubbers.
2. Remove 2 bolts securing remote gear change bracket to extension housing, recover washers and mounting rubbers.
3. Release remote gear change from extension housing, disconnect selector rod from selector shaft pin.




Extension housing - Types A and B gearbox - Remove




37M7056

1. Thread a 12mm bolt into the end of the output shaft and using tool LRT-37-009 and LRT-37-010 withdraw oil seal collar.




37M7057

2. Remove reverse/5th gear selector spool retainer.
3. Remove 10 bolts securing extension casing noting position of longer bolts.
4. Place a suitable container underneath the box to catch any oil spillage and remove the extension housing.
5. Remove oil filter.
6. Secure centre plate to gear casing with 2 8 x 35mm bolts.



37M7058

Extension housing - Type C gearbox - Remove




37M7059

1. Remove and discard self-locking nut securing selector shaft pin to selector shaft; remove pin.
 2. Carefully prise speedometer pinion housing and gear out of extension housing, remove and discard 'O' ring.
 3. Remove 5th gear spool retainer, remove and discard 'O' ring.
 4. Noting their fitted position, remove 10 bolts securing extension housing to gearcase.
 5. Using a soft faced mallet, tap extension housing to free it from locating dowels.
 6. Remove extension housing.
- Note: Speedometer drive gear may be a tight fit on output shaft and this can prevent removal of extension housing. Insert suitable blocks of wood between extension housing and centre plate and carefully lever extension housing away until drive gear is released.*
7. Remove and discard selector shaft oil seal.
 8. Secure centre plate to gearcase with 2 8 x 35mm bolts

MANUAL GEARBOX

5th and Reverse gear - Remove


1. Using a suitable two legged puller remove 5th gear layshaft support bearing track from the end of layshaft.




37M7060

2. Using tool LRT-37-023 to hold the 5th laygear, remove the 5th laygear nut.
3. Remove Thrust collar segments retaining ring and segments.
4. Drift out the roll pin.

5. Remove 5th laygear.
6. Remove mainshaft rear support bearing track using tool LRT-37-009 and LRT-37-024.
7. Remove 12mm bolt from end of mainshaft.
8. Remove mainshaft 5th gear with synchromesh baulk ring.
9. Remove mainshaft 5th gear split needle roller bearing.
10. Remove circlip securing 5th gear synchromesh hub.




37M7061



37M7062

11. Rotate selector spool clear of synchro hub fork and remove 5th and reverse synchromesh hub assembly complete with fork and spool.
12. Remove mainshaft reverse gear complete with needle roller bearing and bush noting selectable spacer between reverse gear bush and centre plate bearing.
13. Remove layshaft reverse gear.




37M7063

14. Remove centre plate detent plug, spring and ball.
15. See *item 3*, Mainshaft and Layshaft - Remove.
16. Remove 'slave' bolts.

Mainshaft and layshaft - Remove

1. Align selector shaft pin with slot in centre plate and using wooden blocks and hide mallet, drive off centre plate.
2. Collect detent ball and spring, remove bearing tracks and shims.
3. Remove main case spool retainer.




37M7064

4. Remove layshaft, mainshaft and selector shaft from casing as complete unit.
5. Remove input shaft, and 4th gear baulk ring. (If not already removed with mainshaft).


Mainshaft - Dismantle

1. Using LRT-99-002 and support bars under 1st gear, press mainshaft support bearing from mainshaft.



37M7065

MANUAL GEARBOX



37M7066


2. Remove 1st gear, bush needle bearing and synchromesh baulk rings.
3. Remove 1st/2nd gear synchromesh selector hub, 2nd gear synchromesh baulk rings, second gear and needle bearing.

Gearbox casing

Degrease and clean all components. Inspect casing for damage, cracks and stripped threads.


1. Fit level plug.
2. Fit new copper washer to drain plug.

Front Cover - Dismantle



37M7067

4. Invert mainshaft and using LRT-99-002 and support bars under 3rd gear, press off pilot bearing
5. Remove spacer, 3rd/4th gear synchromesh selector hub, synchromesh baulk rings, 3rd gear and needle bearing.




37M7068

1. Remove front cover and remove bearing tracks. Check that spring clips are intact.
2. Remove oil seal from cover. DO NOT fit new seal at this stage.



Centre plate - Dismantle




37M7069

1. Remove bearing tracks and shims and check for wear and damage
2. Inspect for damage and selector rail bore for wear.
3. Remove splash shield if required.
4. Press out reverse idler gear shaft using suitable press and check for wear.
5. Remove idler gear, needle bearing and spacer and check for wear and damage.

Extension housing - Types A and B gearbox - Overhaul

1. Examine for damage to threads and machined faces.



37M7070

Note: Types A and B gearbox extension housing shown.

2. Remove three screws and remove oil pump.
3. Remove oil pick-up pipe and check for obstruction.
4. Drift out layshaft support bearing.
5. Remove rear mainshaft oil seal.
6. Drift out mainshaft support bearing and oil pick up ring.
7. Remove shaft retaining reverse inhibition cam.
8. Remove reverse inhibition cam and spring.
9. Remove reverse light switch and sealing washer
10. Remove gate plate.
11. Check all components for wear and renew as required.

Type C gearbox

1. Recover speedometer drive gear and spacer.
2. Check speedometer drive gear for wear and damage, replace if necessary.
3. Check speedometer pinion for wear and damage and that scrolling on shaft is clear; replace pinion and shaft if necessary.
4. Check slots in 5th gear spool guide for wear, replace spool guide if necessary.


Reassembly

1. Smear a light coat of vaseline into the pump recess.
2. Renew 'O' ring and press pump unit firmly into recess.

Note: Ensure 'TOP' marking on pump is to top of casing.

3. Tap pump **lightly** at edges until fully home.


Note: Ensure good thread engagement before tightening.



37M7071

MANUAL GEARBOX

4. Fit new mainshaft support bearing.
5. Fit new mainshaft rear oil seal using tool LRT-37-014.
6. Fit new Layshaft support bearing.
7. Fit new oil pick-up ring (Align tag with centre of drain slot).
8. Examine gate plate and renew if worn or damaged.
9. Refit reverse light switch with new copper washer. Tighten to 22 - 26.5Nm.
10. Refit reverse inhibition cam and spring.
11. Apply Hylogrip 640 and refit shaft.
12. Refit oil pipe, bend uppermost.




37M0535

Gear change/selector housings - Overhaul

Gear change housing - Type A gearbox

Dismantle



37M0534

1. Using a suitable piece of tubing, release both ends of bias spring from ball pins.
2. Slacken locknuts and remove bias spring adjusting screws.
3. Drift out roll pin, remove bias spring.

4. Remove extension from lower gear lever.
5. Remove bolt and special washer securing lower gear lever.
6. Carefully withdraw lower gear lever from housing ensuring that spring loaded nylon pad is retained during removal.

WARNING: Personal injury may result if pad is not retained.

7. Release nylon pad, recover spring.
8. Clean all components.

Inspection

1. Check lower gear lever ball pin for wear, replace if necessary.

CAUTION: If lower gear lever is to be replaced then ball pin seating, located in remote housing should also be replaced.

2. Check nylon pad and spring for wear and damage, replace if necessary.
3. Check bias spring roll pin for damage, replace if necessary.

Reassemble

1. Smear ball pin with multi - purpose grease and fit spring and nylon pad.
2. Depress nylon pad against spring pressure, position lower gear lever in housing.

CAUTION: Ensure nylon pad is facing away from bias spring location.



3. Fit lower gear lever retaining bolt and special washer, tighten bolt to 10 Nm.
4. Fit extension to lower gear lever.
5. Position roll pin to housing, fit roll pin.
6. Fit bias spring adjusting screws and locknuts.
7. Using a suitable piece of tubing locate both ends of bias spring over ball pins.

Note: Do not adjust bias spring at this stage.



Remote housing - Type A gearbox


Dismantle



37M7072

1. Remove setscrew securing trunnion to selector shaft, remove trunnion.
2. Remove and discard circlip securing ball pin seating to trunnion, remove seating.
3. Slacken locknut, remove 5th gear stop screw.

CAUTION: Retain shim(s).



37M7073

4. Remove blanking plug from end of remote housing.
5. Remove setscrew securing quadrant to selector shaft, remove quadrant.
6. Remove selector shaft from remote housing, remove and discard O ring.
7. Remove and discard circlip retaining rollers and pin to quadrant.
8. Remove pin, recover rollers.

Inspection

1. Check selector shaft and bore in remote housing for wear.
2. Check quadrant rollers and pin for wear.
3. Check ball pin seating for wear.
4. Replace worn components as necessary.

Reassemble

1. Lubricate selector shaft and new O ring with gearbox oil.
2. Fit O ring to selector shaft.
3. Fit shaft to remote housing.
4. Position rollers to quadrant, fit pin and secure with new circlip.

CAUTION: Ensure that head of pin is on opposite side of quadrant to selector shaft boss.

5. Fit quadrant to selector shaft.
6. Apply Loctite 270 to threads of setscrew, fit and tighten setscrew.
7. Apply Loctite 270 to threads of blanking plug, fit and tighten plug.
8. Smear ball pin seating with multi - purpose grease.
9. Position ball pin seating in trunnion, secure with a new circlip.
10. Position trunnion on selector shaft.
11. Apply Loctite 270 to threads of setscrew, fit and tighten setscrew.
12. Fit 5th gear stop screw, fit but do not tighten locknut.


Note: 5th gear stop screw adjustment is carried out during gearbox reassembly.

Gear change housing - Type B gearbox

Dismantle

1. Remove bolts retaining bias springs.


WARNING: To avoid personal injury, restrain each spring in turn with a pair of grips while the bolts are being removed.



37M7074

MANUAL GEARBOX

2. Remove the two springs.
3. Remove remaining bolts to release lower lever assembly.
4. Remove and discard Railko bush.
5. Remove and discard oil seal.



37M7075

Inspection

1. Check ball cross pin slots in gear change housing for wear.
2. Check ball and pins for wear.
3. Check bias springs for distortion.
4. Replace worn components as necessary.

Reassemble

1. Apply multi-purpose grease to ball and cross pins.
2. Apply multi-purpose grease to new Railko bush and fit to gear change housing.

CAUTION: Ensure that the slots in each bush are aligned with slots in housing.



3. Lubricate a new oil seal with gearbox oil.
4. Fit oil seal using a suitable mandrel.
5. Position gear lever to gear change housing ensuring ball cross pins are located in slots in housing and Railko bush.
6. Position bias spring adjustment plate to gear change housing,
7. Apply Loctite 270 to threads of 2 short bias adjustment plate bolts.
8. Fit bolts to secure front of bias adjustment plate and tighten to 25 Nm.
9. Position bias spring to pillar ensuring longest end of spring is against gear lever.
10. Apply Loctite 270 to threads of 2 long bias adjustment plate bolts.
11. Restrain bias spring using a suitable pair of grips, ensure short end of bias spring is positioned on outside edge of bolt hole.

WARNING: Personal injury may result if bias spring is not retained.

12. Fit bolt and washer ensuring end of bias spring is retained beneath washer; tighten bolt to 25 Nm.
13. Repeat procedure for remaining bias spring.

Remote gear change - Type C gearbox

Dismantle



37M7076

1. Remove 2 bolts and 2 countersunk screws securing bias spring bridge plates
2. Remove bridge plates, bridge plate liners and bias spring.
3. Remove 4 bolts and washers securing bottom cover plate, remove plate.
4. Remove bolt securing gear lever cap, remove cap.
5. Remove gear lever, recover anti-rattle spring and plunger.
6. Remove pinch bolt securing selector rod yoke, remove yoke.
7. Withdraw selector rod from remote housing.
8. Clean components.

Inspection

1. Check selector rod bushes in remote housing for wear.

Note: Bushes may be pressed in and out of remote housing using a hand press and suitable mandrel.

2. Check selector rod for wear, replace if necessary.



3. Check anti - rattle spring for distortion and plunger for wear; replace if necessary.
4. Check gear lever ball pin, cross pins and bush selector rod yoke balls for wear, and replace if necessary. If yoke balls are worn, remove and discard circlip, press ball and seating out of yoke.
5. Lubricate replacement ball and seating with multi - purpose grease and press into yoke; secure using new circlip.
6. Check bias spring for distortion, replace if necessary.
7. Check condition of mounting rubbers, replace as a set if necessary.


Reassemble

1. Lubricate selector rod and bushes with multi - purpose grease, insert rod in remote housing.
 2. Lubricate gear lever ball pin and selector rod yoke balls with multi - purpose grease.
 3. Fit yoke to selector rod, fit and tighten pinch bolt.
 4. Assemble anti - rattle spring and plunger to gear lever.
 5. Fit gear lever ensuring ball pin is located in yoke and anti - rattle spring and plunger are not displaced.
 6. Fit gear lever cap, fit and tighten bolt.
- Note:** Do not fit bottom cover plate at this stage.
7. Slacken bias spring adjustment bolt locknuts.
 8. Fit bias spring, bridge plate liners and bridge plates.
 9. Fit and tighten bolts and countersunk screws.

Note: Final adjustment of bias spring is carried out after remote gear change is fitted to gearbox.


Transfer box selector housing - Type A gearbox - Overhaul

Dismantle




37M0618

1. Slide gaiter off gear lever.
2. Remove 4 bolts securing gaiter support plate and gate plate.
3. Remove gaiter support plate and gate plate, discard gaskets.



37M0619


4. Remove and discard spring clip retaining selector fork clevis pin.
5. Remove clevis pin from selector fork, remove and discard 2 bushes.



37M0620

6. Remove and discard circlip retaining nylon ball seating.
7. Remove gear lever, recover nylon seating and ball.

MANUAL GEARBOX



37M0544

8. Remove 2 countersunk head screws securing end cover to housing.
9. Remove end cover, remove and discard 2 'O' rings.
10. Withdraw cross shaft.
11. Remove selector fork, remove and discard 2 'O' rings.
12. Clean all components.

Inspection

1. Check gaiter for splits and damage.
2. Check nylon seating and ball for wear, replace if necessary.


CAUTION: Seating and ball should be renewed as an assembly.

3. Check selector fork and clevis pin for wear.
4. Check cross shaft and end cover for wear.
5. Replace components as necessary.


Reassemble

1. Smear new 'O' rings with gearbox oil and fit to selector fork, position fork in housing.
2. Smear cross shaft with multi - purpose grease and locate longest end of shaft in selector fork.
3. Smear new 'O' rings with gearbox oil and fit to end cover.
4. Position end cover on cross shaft, fit and tighten countersunk screws.
5. Assemble ball and nylon seating to gear lever ensuring that groove in seating is towards cross shaft.
6. Smear ball and nylon seating with multi - purpose grease and locate in cross shaft; retain with a new circlip.
7. Position new bushes to gear lever, locate in selector fork and fit clevis pin.
8. Fit new spring clip to retain clevis pin.
9. Position gate plate and gaiter support plate to housing, use new gaskets.
10. Fit retaining bolts and tighten to 15 Nm.
11. Fit gaiter.

Synchromesh assemblies - Overhaul



1. Remove spring clips from both sides of assembly.
2. Remove slippers and separate the hub from the sleeve.
3. Examine all parts for damage and wear including spring clips for tension.
4. Check no excessive radial movement exist between inner members and mainshaft splines.
5. Examine inner and outer splines for wear.
6. Examine the dog teeth on all gears for wear and damage.



Note: Example 'A' shows a tooth in good condition. Example 'B' shows the rounded corners of a worn tooth.

7. Replace unit if excessively worn.



Reassembly

8. Refit inner hub to sleeve.

Note: Hubs and sleeves have a master spline combination and can only be assembled one way. The sleeves are further identified with a series of half moon notches which clearly identify which side of the assembly faces which gear. Ensure the slot in the hub aligns with the centre notch on the sleeve.

Assy	Hub	Sleeve	Against Gear
1st/2nd	-	1 Notch	1st
	2 gear side	-	2nd
3rd/4th	-	3 Notches	3rd
	-	-	4th
5th/Rev	-	5 Notches	5th

9. Fit slippers and secure with a spring each side of the synchromesh assembly ensuring the step on each spring locates on a different slipper.

Note: 5th and reverse synchromesh hubs have different springs noted by their yellow colour.

Checking baulk ring clearances


Check clearance of all baulk rings and gears by pressing the baulk rings against the gear and measuring the gap. The minimum clearance should be 0.5mm (0.020in).



37M7079

Input shaft - Overhaul


1. Examine the gear and dog teeth for wear and damage.



37M7080

2. Using tool LRT-99-004 and LRT-37-004 remove pilot bearing track.


Note: Ensure that the bearing is supported by the lip inside LRT-37-001.



37M7081

3. Using LRT-37-001 and LRT-99-002 remove taper roller bearing.

4. Support the shaft under LRT-99-002 and press in a new pilot bearing track.




37M7082

5. Using LRT-99-002, Collets LRT-37-001 and adapter LRT-37-002 fit a new taper bearing.

MANUAL GEARBOX

Mainshaft - Inspection




37M0783

1. Examine bearing journals for wear and scores.
2. Examine splines for wear and damage.
3. Use an air line to check that the main oil feed from pump and feed to spigot bearing are clear.
4. Check oil feed holes to roller bearing are clear.


Layshaft - Overhaul

1. Using extractor tool LRT-99-002 and collets LRT-37-022 withdraw layshaft bearings.
2. Examine layshaft for wear and damage.



37M7084


3. Using press LRT-99-002, and support bars fit new taper roller bearings.



37M7085

Mainshaft - Reassembly

1. Clamp mainshaft in protected vice jaws, output end upwards.
2. Fit 2nd gear needle roller bearing, 2nd gear and synchromesh baulk rings onto mainshaft. *(Rotate each baulk ring to ensure they locate onto each other).*
3. Assemble the 1st and 2nd synchromesh selector hub onto mainshaft spline, *(note 2nd speed side marking)*. Ensure that baulk ring has located correctly inside hub. *(Rotate the ring slightly as the hub is lowered).*
4. Fit 1st gear synchromesh baulk rings, needle roller bearing, 1st gear and bush onto mainshaft ensuring baulk rings locate correctly inside selector hub.
5. Using LRT-99-002, bearing guide LRT-37-019, collets LRT-37-001 and adaptor LRT-37-002 press on mainshaft taper roller bearing taking care not to disturb the lay of the synchromesh baulk rings and gears.
6. Check the end float of the 1st and 2nd gear assembly using a feeler gauge between the gear and mainshaft bearing.
Maximum clearance:
1st gear: 0.05 - 0.20mm (0.002 - 0.008 in)
2nd gear: 0.04 - 0.21mm (0.0016 - 0.0083 in)
7. Invert mainshaft in vice and fit 3rd gear needle roller bearing, third gear and synchromesh baulk rings.
8. Assemble 3rd/4th gear synchromesh selector hub *(note 3rd speed side markings)* onto mainshaft splines taking care to locate the baulk rings into recesses in the selector hub.
9. Fit spacer.




37M7086

10. Using LRT-99-002 press on new pilot bearing. Check end float of 3rd gear assembly as in step 6.
Maximum clearance:
0.11 - 0.21mm (0.004 - 0.0083 in).

MANUAL GEARBOX

Reverse idle gear - Reassembly

1. Examine components for wear and damage.




37M7087

2. Assemble reverse idle gear needle roller bearing, idle gear, spacer and shaft and using suitable tool, press into centre plate.
Maximum clearance:
0.04 - 0.38mm (0.0016in - 0.015in)

Selectors - Inspection

1. Examine selector rail and pins for wear and damage.




37M7088

2. Examine selector forks for wear and damage.
Note: The selector rail and fork is only supplied as a complete assembly.
3. Examine interlock spools for wear and damage.


Selector quadrant - Type A gearbox

Examine selector quadrant and check for wear.



37M7089

Selector yoke - Type B gearbox




37M7090

4. Remove snap ring and examine selector yoke assembly.


Assembling selectors.

1. Rest 1st/2nd fork and shaft assembly on bench and locate pin in jaw of fork.
2. Fit interlock spool and 3rd/4th fork and engage spool in jaw of fork.



37M7091

3. Slide spool and fork towards 1st/2nd selector until slot in spool locates over pin keeping the spool engaged in 3rd/4th fork jaw.



37M7092



GEARBOX REASSEMBLE

Mainshaft and layshaft end float


Note: The end float setting for both the mainshaft and the layshaft has to be determined before the gear box can be reassembled. This is achieved by clamping the mainshaft and layshaft separately between the centre plate and main casing and measuring the movement on each shaft with a Dial test indicator.

The end float setting for the mainshaft and layshaft is 0.01 - 0.06mm (0.0004 - 0.0024in).

Shims to make up the required clearances are placed under the bearing tracks of the centre plate.

Shimming

1. Fit bearing tracks to main casing front cover.
2. Fit front cover to casing without oil seal.




37M7093

3. Clamp casing in vice with front cover downwards.
4. Fit input shaft. Do not fit 4th gear baulk ring.
5. Fit mainshaft assembly to input shaft.
6. Fit mainshaft bearing shim and track to centre plate.

7. Fit centre plate and bolt down using 8 'slave' bolts.
8. Fit large ball bearing to rear of mainshaft.
9. Mount dial test indicator.
10. Rotate mainshaft to settle bearings.
11. Lift mainshaft and note reading.
12. Dismantle and substitute shims if reading incorrect.
13. Repeat procedure.
14. Remove mainshaft assembly and repeat procedure for layshaft.
15. Dismantle assembly in preparation for assembly on stand.

Assembling mainshaft and layshaft to centre plate


1. Secure centre plate to workstand.
2. Fit selected shims and bearing tracks.
3. Fit inboard detent ball and spring, use a dummy bar to temporarily hold the ball in place.
4. Check both synchromesh units are in neutral and fit selector shaft assembly to mainshaft.



37M7094


5. Fit mainshaft and selectors as complete unit to centre plate aligning pin with slot in plate.
6. Fit 4th gear synchromesh baulk ring.

MANUAL GEARBOX



37M7095

7. Fit layshaft whilst lifting mainshaft to clear layshaft rear bearing.
8. Lubricate pilot bearing and fit input shaft.




37M7096

9. Fit oil seal to front cover. Ensure seal is fitted down to shoulder. Apply Hylogrip 2000 as shown.
10. Fit bearing tracks and clips to main case and fit front cover. Seal fixings with Hylogrip 640.
11. Apply Hylogrip 2000 and fit main casing to centre plate.

12. Bolt casing and centre plate together using 2 or 3 'slave' bolts.
13. Fit new 'O' ring and fit spool retainer.
14. Remove casing from stand and clamp in vice.


Reverse and 5th gear - Reassembly

1. Fit mainshaft reverse gear selectable washer, bush and needle bearing.
2. Fit mainshaft reverse gear and synchromesh baulk ring.
3. Fit layshaft reverse gear.



37M7097


4. Assemble selector spool, selector fork and reverse /5th gear synchromesh hub. Fit as one assembly to mainshaft splines and selector shaft. (Ensure synchromesh baulk ring locates inside hub)




37M7098

5. Fit new circlip.
- Note:** The fit of the circlip is controlled by the selectable washer behind the reverse gear. Adjust to 0.005 - 0.055mm (0.0002 - 0.0021).
6. Fit 5th gear split needle bearing.
7. Fit 5th gear and 5th gear synchromesh baulk ring to mainshaft.
8. Fit layshaft 5th gear.
9. Fit new mainshaft thrust collar roll pin. Locate 5th gear thrust segments and retaining ring.
10. Using LRT-37-023 to hold layshaft 5th gear, tighten the Layshaft 5th gear nut to 204 - 231 Nm.
11. Stake layshaft 5th gear nut.

12. Using tool LRT-37-015 and LRT-37-21 press mainshaft rear support bearing track to collar on mainshaft.
13. Apply small amount of heat and fit layshaft rear support bearing.



37M7099




37M7100

MANUAL GEARBOX

Extension housing - Type A and B Gearbox - Refit

1. Remove all 'slave' bolts from centre plate and casing.
2. Refit oil filter.




37M7101

3. Apply Hylogrip 2000 to mating surfaces and fit extension housing ensuring oil pipe locates in filter and roller bearings are not dislodged.


CAUTION: Do not use force, if necessary, remove extension housing and re-align oil pump drive.

4. Bolt extension housing to centre plate and main casing.



37M7102

5. Apply Hylogrip 2000 and fit extension case spool retainer.



37M7103

6. Using LRT-37-015 and LRT-37-21 press on mainshaft oil seal collar.

Extension housing - Type C gearbox - Refit


1. Lubricate a new selector shaft oil seal with gearbox oil.
2. Fit selector shaft oil seal.
3. Refit oil filter.
4. Apply Hylogrip 200 to mating surfaces.
5. Fit extension housing ensuring oil pick-up pipe locates in filter and drive locates in oil pump.

CAUTION: Do not use force, if necessary, remove extension housing and re-align oil pump drive.

6. Fit extension housing bolts and tighten by diagonal selection to 25 Nm.
7. Fit spacer
8. Position speedometer drive gear on output shaft splines.
9. Using a round nosed punch, carefully tap speedometer drive gear into position.
10. Smear a new 'O' ring with gearbox oil and fit to speedometer pinion housing.
11. Lubricate speedometer pinion with silicone grease.
12. Fit speedometer pinion housing ensuring teeth of pinion mesh with those of driven gear.
13. Apply Hylogrip 2000 and fit 5th gear spool guide. Tighten bolt to 10 Nm.
14. Fit selector shaft pin to selector shaft, fit and tighten a new self-locking nut.
15. Fit output flange to output shaft.
16. Fit new 'O' ring and spacer.
17. Fit new tab washer.
18. Fit output flange bolt and tighten to 80 - 100 Nm.
19. Lock bolt with tab washer.



Selector quadrant - Type A gearbox - Refit




37M7104

1. Position selector quadrant to selector shaft.
2. Apply Loctite 270 to thread of a new setscrew. Fit and tighten screw to 22 - 28 Nm.
3. Move selector shaft to neutral position.

CAUTION: Ensure end of setscrew locates in hole in selector shaft.

Gear change lever yoke - Type B gearbox - Refit




37M7105

1. Position gear change lever yoke on selector shaft with ball facing towards output shaft.
2. Apply Loctite 270 to threads of a new setscrew, fit and tighten screw.

CAUTION: Ensure end of setscrew locates in hole in selector shaft.

Remote housing - Type A gearbox - Refit

1. Apply Hylogrip 2000 to mating surfaces and fit to extension housing.
2. Position remote housing to extension housing and gearcase ensuring rollers locate in quadrant.



37M7106

3. Fit but do not fully tighten 3 bolts in positions shown.

MANUAL GEARBOX

Transfer box selector housing - Type A gearbox - Refit

1. Smear a new gasket with grease and fit to remote housing.
2. Position transfer box selector housing to remote housing.
3. Fit but do not fully tighten 4 bolts.


Gear change housing - Type A gearbox - Refit

1. Smear a new gasket with grease and fit to remote housing.
2. Position gear change housing to remote housing ensuring gear lever ball is correctly located.
3. Fit but do not fully tighten 4 bolts.
4. Tighten remote housing, transfer box selector housing and gear change housing bolts to 25 Nm.

Transfer box selector housing - Type B gearbox - Refit

1. Smear a new gasket with grease and fit to gearcase.
2. Position transfer box selector housing to gearcase, fit 4 bolts and tighten to 25 Nm.

Gear change housing - Type B gearbox - Refit



37M7107

1. Apply Hylogrip 2000 to mating surfaces of extension housing.
2. Position gear change housing to extension housing ensuring that gear lever passes through centre of gear change lever yoke and engages in the gate plate.
3. Fit bolts and tighten to 25 Nm.

Remote gear change - Type C gearbox - Refit


1. Apply lithium based grease to selector rod yoke.
2. Position remote gear change to extension housing ensuring selector shaft pin is located in selector rod yoke.
3. Fit bolts, washers and mounting rubbers securing remote gear change to extension housing; do not tighten bolts at this stage.
4. Fit bolts, washers and mounting rubbers securing bracket to extension housing.
5. Tighten all bolts to 35 Nm.

5th gear stop screw adjustment - Type A gearbox

1. Select reverse gear. While applying light pressure to gear lever towards right, turn screw clockwise until it contacts yoke.
2. Turn screw anti-clockwise until 25mm free play is felt at knob, ensure 5th gear can be engaged.
3. Tighten locknut.
4. Check all other gears are selectable.

Bias spring adjustment - Type A gearbox

Note: The purpose of this adjustment is to set both bolts so that the bias spring legs apply equal pressure on both ends of the gear lever cross pin when third or fourth gear is engaged. This will ensure that when the lever is in neutral, the gear change mechanism is automatically aligned for third or fourth gear.




37M108

1. Select third or fourth gear.
2. Adjust the two adjusting screws until both legs of the spring are approximately 0.5mm clear of the cross pin in the gear lever.




3. Apply a light load to the gear lever in a left hand direction and adjust the right hand adjusting screw downward until the right hand spring leg just makes contact with the cross pin.
4. Repeat the same procedure for the left hand adjusting screw.
5. Lower both adjusting screws equal amounts until the radial play is just eliminated.
6. Tighten locknuts.
7. Return gear lever to neutral position and rock across the gate several times. The gear lever should return to the third and fourth gear.

Bias spring adjustment - Type B gearbox



37M7109

1. Slacken bias adjustment plate bolts. Select fourth gear and move lever fully to the right.
2. Tighten adjustment plate bolts.
3. Check adjustment is correct by selecting third and fourth gears.





37M7110

4. Fit sealing rubber to gear change housing, apply Hylogip 640 to screws and fit cover.

Bias spring adjustment - Type C gearbox

Note: The purpose of this adjustment is to ensure that when bias spring is correctly adjusted, the gear change mechanism is automatically aligned for 3rd or 4th gear selection when gear lever is in neutral.




37M7111

1. Adjust both bias spring adjustment bolts until a clearance of 0.05mm exists between both legs of bias spring and gear lever cross pin.
2. Apply a light load to move gear lever to the left and adjust right hand bolt until right hand leg of bias spring just contacts gear lever cross pin.
3. Move gear lever to the right and adjust left hand bolt.
4. Check that with gear lever moved fully to the left and right, spring legs just contact gear lever cross pin.
5. Select neutral then rock gear lever across the gate; when released, lever should return to 3rd/4th position.
6. Tighten adjusting bolt locknuts.

MANUAL GEARBOX

Clutch housing - Type A gearbox - Refit



37M7112

1. Position clutch housing to gearbox.
2. Fit securing bolts.


Note: The 12 x 45mm bolts must be fitted through locating dowels.

3. Tighten bolts by diagonal selection to 75 Nm.
4. Fit pivot post, fit and tighten bolts.
5. Apply lithium based grease to pivot post, pads and push rod.
6. Position pads to clutch release lever, fit release bearing.
7. Fit new clips to retain pads.

Note: Clips may become displaced in service with no loss of performance.

8. Fit release lever.
9. Apply lithium based grease to splines of input shaft.

Clutch housing - Type B gearbox - Refit



37M0616

1. Position clutch housing to gearbox.
2. Fit securing bolts.

Note: The 12 x 45mm bolts must be fitted through locating dowels.

3. Tighten bolts by diagonal selection to 75 Nm.
4. Apply lithium based grease to pivot post, release lever, socket and push rod.
5. Fit a new 'C' clip to pivot post, fit post.
6. Fit spring clip to release lever, fit but do not tighten bolt.
7. Position release lever to pivot post ensuring spring clip is located behind 'C' clip; tighten bolt.
8. Fit clutch release bearing and retain using new clips.

Note: Clips may become displaced in service with no loss of performance.



Clutch housing - Type C gearbox - Refit

1. Position clutch housing to gearbox.
2. Fit securing bolts.

Note: *The 2 longest bolts must be fitted at locating dowel positions*

3. Tighten bolts by diagonal selection to 75 Nm.
4. Apply lithium based grease to pivot post.
5. Fit release lever and clutch release bearing.